

System event messages log

The system event messages log contains messages of three types:

Information

Information messages do not require action; they record significant system-level events, such as when the server is started.

Warning

Warning messages do not require immediate action; they indicate possible problems, such as when the recommended maximum ambient temperature is exceeded.

Error Error messages might require action; they indicate system errors, such as when a fan is not detected.

Each message contains date and time information, and it indicates the source of the message (POST or the IMM).

Integrated management module error messages

Table 9. Integrated management module error messages

Message	Severity	Description	Action
<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Numeric sensor Ambient Temp going high (upper critical) has asserted.	Error	An upper critical sensor going high has asserted.	Reduce the ambient temperature.
Numeric sensor Ambient Temp going high (upper non-recoverable) has asserted.	Error	An upper nonrecoverable sensor going high has asserted.	Reduce the ambient temperature.
Numeric sensor Planar 3.3V going low (lower critical) has asserted.	Error	A lower critical sensor going low has asserted.	(Trained service technician only) Replace the system board.
Numeric sensor Planar 3.3V going high (upper critical) has asserted.	Error	An upper critical sensor going high has asserted.	(Trained service technician only) Replace the system board.
Numeric sensor Planar 5V going low (lower critical) has asserted.	Error	A lower critical sensor going low has asserted.	(Trained service technician only) Replace the system board.
Numeric sensor Planar 5V going high (upper critical) has asserted.	Error	An upper critical sensor going high has asserted.	(Trained service technician only) Replace the system board.
Numeric sensor Planar 12V going low (lower critical) has asserted.	Error	A lower critical sensor going low has asserted.	Check the OVER SPEC LED and power-channel (A, B, C, D, E, and AUX) error LEDs on the system board. See the information about the OVER SPEC LED in “Light path diagnostics LEDs” on page 57.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Numeric sensor Planar 12V going high (upper critical) has asserted.	Error	An upper critical sensor going high has asserted.	Check the OVER SPEC LED and power-channel (A, B, C, D, E, and AUX) error LEDs on the system board. See the information about the OVER SPEC LED in “Light path diagnostics LEDs” on page 57.
Numeric sensor Planar VBAT going low (lower critical) has asserted.	Error	A lower critical sensor going low has asserted.	Replace the 3 V battery.
Numeric sensor Fan <i>n</i> A Tach going low (lower critical) has asserted. (<i>n</i> = fan number)	Error	A lower critical sensor going low has asserted.	<ol style="list-style-type: none"> 1. Reseat the failing fan <i>n</i>, which is indicated by a lit LED near the fan connector on the system board. 2. Replace the failing fan. (<i>n</i> = fan number)
Numeric sensor Fan <i>n</i> B Tach going low (lower critical) has asserted. (<i>n</i> = fan number)	Error	A lower critical sensor going low has asserted.	<ol style="list-style-type: none"> 1. Reseat the failing fan <i>n</i>, which is indicated by a lit LED near the fan connector on the system board. 2. Replace the failing fan. (<i>n</i> = fan number)
The connector System board has encountered a configuration error.	Error	An interconnect configuration error has occurred.	Reseat the front video cable on the system board.
The Processor CPU <i>n</i> Status has Failed with IERR. (<i>n</i> = microprocessor number)	Error	A processor failed - IERR condition has occurred.	<ol style="list-style-type: none"> 1. Make sure that the latest levels of firmware and device drivers are installed for all adapters and standard devices, such as Ethernet, SCSI, and SAS. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 2. Run the DSA program for the hard disk drives and other I/O devices. 3. (Trained service technician only) Replace microprocessor <i>n</i>. (<i>n</i> = microprocessor number)

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
<p>An Over-Temperature Condition has been detected on the Processor CPU <i>n</i>Status. (<i>n</i> = microprocessor number)</p>	<p>Error</p>	<p>An overtemperature condition has occurred for microprocessor <i>n</i>. (<i>n</i> = microprocessor number)</p>	<ol style="list-style-type: none"> 1. Make sure that the fans are operating, that there are no obstructions to the airflow, that the air baffles are in place and correctly installed, and that the server cover is installed and completely closed. 2. Make sure that the heat sink for microprocessor <i>n</i> is installed correctly. 3. (Trained service technician only) Replace microprocessor <i>n</i>. <p>(<i>n</i> = microprocessor number)</p>
<p>The Processor CPU <i>n</i>Status has Failed with FRB1/BIST condition. (<i>n</i> = microprocessor number)</p>	<p>Error</p>	<p>A processor failed - FRB1/BIST condition has occurred.</p>	<ol style="list-style-type: none"> 1. Check for a UEFI firmware update. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 2. Make sure that the installed microprocessors are compatible with each other (see “Installing a microprocessor and heat sink” on page 194 for information about microprocessor requirements). 3. (Trained service technician only) Reseat microprocessor <i>n</i>. 4. (Trained service technician only) Replace microprocessor <i>n</i>. <p>(<i>n</i> = microprocessor number)</p>

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
<p>The Processor CPU <i>n</i>Status has a Configuration Mismatch. (<i>n</i> = microprocessor number)</p>	<p>Error</p>	<p>A processor configuration mismatch has occurred.</p>	<ol style="list-style-type: none"> 1. Make sure that the installed microprocessors are compatible with each other (see “Installing a microprocessor and heat sink” on page 194 for information about microprocessor requirements). 2. (Trained service technician only) Replace the incompatible microprocessor.
<p>An SM BIOS Uncorrectable CPU complex error for Processor CPU <i>n</i>Status has asserted. (<i>n</i> = microprocessor number)</p>	<p>Error</p>	<p>An SMBIOS uncorrectable CPU complex error has asserted.</p>	<ol style="list-style-type: none"> 1. Check for a UEFI firmware update. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 2. Make sure that the installed microprocessors are compatible with each other (see “Installing a microprocessor and heat sink” on page 194 for information about microprocessor requirements). 3. (Trained service technician only) Reseat microprocessor <i>n</i>. 4. (Trained service technician only) Replace microprocessor <i>n</i>. <p>(<i>n</i> = microprocessor number)</p>

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
<p>Sensor CPU <i>n</i>OverTemp has transitioned to critical from a less severe state. (<i>n</i> = microprocessor number)</p>	Error	A sensor has changed to Critical state from a less severe state.	<ol style="list-style-type: none"> 1. Make sure that the fans are operating, that there are no obstructions to the airflow, that the air baffles are in place and correctly installed, and that the server cover is installed and completely closed. 2. Make sure that the heat sink for microprocessor <i>n</i> is installed correctly. 3. (Trained service technician only) Replace microprocessor <i>n</i>. <p>(<i>n</i> = microprocessor number)</p>
<p>Sensor CPU <i>n</i>OverTemp has transitioned to non-recoverable from a less severe state. (<i>n</i> = microprocessor number)</p>	Error	A sensor has changed to Nonrecoverable state from a less severe state.	<ol style="list-style-type: none"> 1. Make sure that the fans are operating, that there are no obstructions to the airflow, that the air baffles are in place and correctly installed, and that the server cover is installed and completely closed. 2. Make sure that the heat sink for microprocessor <i>n</i> is installed correctly. 3. (Trained service technician only) Replace microprocessor <i>n</i>. <p>(<i>n</i> = microprocessor number)</p>
<p>Sensor CPU <i>n</i>OverTemp has transitioned to critical from a non-recoverable state. (<i>n</i> = microprocessor number)</p>	Error	A sensor has changed to Critical state from Nonrecoverable state.	<ol style="list-style-type: none"> 1. Make sure that the fans are operating, that there are no obstructions to the airflow, that the air baffles are in place and correctly installed, and that the server cover is installed and completely closed. 2. Make sure that the heat sink for microprocessor <i>n</i> is installed correctly. 3. (Trained service technician only) Replace microprocessor <i>n</i>. <p>(<i>n</i> = microprocessor number)</p>

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Sensor CPU <i>n</i> OverTemp has transitioned to non-recoverable. (<i>n</i> = microprocessor number)	Error	A sensor has changed to Nonrecoverable state.	<ol style="list-style-type: none"> 1. Make sure that the fans are operating, that there are no obstructions to the airflow, that the air baffles are in place and correctly installed, and that the server cover is installed and completely closed. 2. Make sure that the heat sink for microprocessor <i>n</i> is installed correctly. 3. (Trained service technician only) Replace microprocessor <i>n</i>. <p>(<i>n</i> = microprocessor number)</p>
A diagnostic interrupt has occurred on system %1. (%1 = CIM_ComputerSystem.ElementName)	Error	An operator information panel NMI/diagnostic interrupt has occurred.	<p>If the NMI button on the operator information panel has not been pressed, complete the following steps:</p> <ol style="list-style-type: none"> 1. Make sure that the NMI button is not pressed. 2. Replace the operator information panel cable. 3. Replace the operator information panel.
A bus timeout has occurred on system %1. (%1 = CIM_ComputerSystem.ElementName)	Error	A bus timeout has occurred.	<ol style="list-style-type: none"> 1. Remove the adapter from the PCI slot that is indicated by a lit LED. 2. Replace the riser-card assembly. 3. Remove all PCI adapters. 4. (Trained service technicians only) Replace the system board.
A software NMI has occurred on system %1. (%1 = CIM_ComputerSystem.ElementName)	Error	A software NMI has occurred.	<ol style="list-style-type: none"> 1. Check the device driver. 2. Reinstall the device driver.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
<p>The System %1 encountered a POST Error. (%1 = CIM_ComputerSystem.ElementName)</p>	Error	<p>A POST error has occurred. (Sensor = ABR Status)</p>	<ol style="list-style-type: none"> 1. Recover the UEFI firmware from the backup page: <ol style="list-style-type: none"> a. Restart the server. b. At the prompt, press F3 to recover the firmware. 2. Update the UEFI firmware to the latest level. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
<p>The System %1 encountered a POST Error. (%1 = CIM_ComputerSystem.ElementName)</p>	Error	<p>A POST error has occurred. (Sensor = Firmware Error)</p>	<ol style="list-style-type: none"> 1. Update the UEFI firmware on the primary page. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 2. (Trained service technician only) Replace the system board.
<p>A Uncorrectable Bus Error has occurred on system %1. (%1 = CIM_ComputerSystem.ElementName)</p>	Error	<p>A bus uncorrectable error has occurred. (Sensor = Critical Int PCI)</p>	<ol style="list-style-type: none"> 1. Check the system-event log. 2. Check the PCI error LEDs. 3. Remove the adapter from the indicated PCI slot. 4. Check for a UEFI firmware update. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 5. (Trained service technician only) Replace the system board.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
<p>A Uncorrectable Bus Error has occurred on system %1. (%1 = CIM_ComputerSystem.ElementName)</p>	<p>Error</p>	<p>A bus uncorrectable error has occurred. (Sensor = Critical Int CPU)</p>	<ol style="list-style-type: none"> 1. Check the system-event log. 2. Check the microprocessor error LEDs. 3. Remove the failing microprocessor from the system board. 4. Check for a UEFI firmware update. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 5. Make sure that the two microprocessors are matching. 6. (Trained service technician only) Replace the system board.
<p>A Uncorrectable Bus Error has occurred on system %1. (%1 = CIM_ComputerSystem.ElementName)</p>	<p>Error</p>	<p>A bus uncorrectable error has occurred. (Sensor = Critical Int DIM)</p>	<ol style="list-style-type: none"> 1. Check the system-event log. 2. Check the DIMM error LEDs. 3. Remove the failing DIMM from the system board. 4. Check for a UEFI firmware update. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 5. Make sure that the installed DIMMs are supported and configured correctly. 6. (Trained service technician only) Replace the system board.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Sensor Sys Board Fault has transitioned to critical from a less severe state.	Error	A sensor has changed to Critical state from a less severe state.	<ol style="list-style-type: none"> 1. Check the system-event log. 2. Check for an error LED on the system board. 3. Replace any failing device. 4. Check for a UEFI firmware update. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 5. (Trained service technician only) Replace the system board.
The Power Supply (Power Supply: <i>n</i>) has Failed. (<i>n</i> = power supply number)	Error	Power supply <i>n</i> has failed. (<i>n</i> = power supply number)	<ol style="list-style-type: none"> 1. If the power-on LED is lit, complete the following steps: <ol style="list-style-type: none"> a. Reduce the server to the minimum configuration. b. Reinstall the components one at a time, restarting the server each time. c. If the error recurs, replace the component that you just reinstalled. 2. Reseat power supply <i>n</i>. 3. Replace power supply <i>n</i>. (<i>n</i> = power supply number)
Sensor PS <i>n</i> Fan Fault has transitioned to critical from a less severe state. (<i>n</i> = power supply number)	Error	A sensor has changed to Critical state from a less severe state.	<ol style="list-style-type: none"> 1. Make sure that there are no obstructions, such as bundled cables, to the airflow from the power-supply fan. 2. Replace power supply <i>n</i>. (<i>n</i> = power supply number)

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Sensor VT Fault has transitioned to non-recoverable.	Error	A sensor has changed to Nonrecoverable state.	<ol style="list-style-type: none"> 1. Check the power-supply LEDs. 2. Follow the actions in Table 7 on page 61. 3. Replace the failing power supply. 4. (Trained service technician only) Replace the system board.
Sensor Pwr Rail A Fault has transitioned to non-recoverable.	Error	A sensor has changed to Nonrecoverable state.	<ol style="list-style-type: none"> 1. Turn off the server and disconnect it from power. 2. Remove the optical drive, fans, hard disk drives, and hard disk drive backplane. 3. Restart the server. 4. Reinstall each device, one at a time, starting the server each time to isolate the failing device. 5. Replace the failing device. 6. (Trained service technician only) Replace the system board.
Sensor Pwr Rail B Fault has transitioned to non-recoverable.	Error	A sensor has changed to Nonrecoverable state.	<ol style="list-style-type: none"> 1. Turn off the server and disconnect it from power. 2. Remove the optical drive, fans, hard disk drives, and hard disk drive backplane. 3. Restart the server. 4. Reinstall each device, one at a time, starting the server each time to isolate the failing device. 5. Replace the failing device. 6. (Trained service technician only) Replace the system board.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Sensor Pwr Rail C Fault has transitioned to non-recoverable.	Error	A sensor has changed to Nonrecoverable state.	<ol style="list-style-type: none"> 1. Turn off the server and disconnect it from power. 2. (Trained service technician only) Remove the SAS/SATA RAID riser card, the DIMMs in connectors 1 through 8, and the microprocessor in socket 1. Note: The server will not start when no microprocessor is installed in socket 1. Toggle switch block SW4 bit 8 to allow the server to start. (For the location of switch block SW4, see “System-board switches and jumpers” on page 16). 3. Restart the server. 4. Reinstall each device, one at a time, starting the server each time to isolate the failing device. 5. Replace the failing device. 6. (Trained service technician only) Replace the system board.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Sensor Pwr Rail D Fault has transitioned to non-recoverable.	Error	A sensor has changed to Nonrecoverable state.	<ol style="list-style-type: none"> 1. Turn off the server and disconnect it from power. 2. (Trained service technician only) Remove the microprocessor from socket 1. Note: The server will not start when no microprocessor is installed in socket 1. Toggle switch block SW4 bit 8 to allow the server to start. (For the location of switch block SW4, see “System-board switches and jumpers” on page 16) 3. Restart the server. 4. Reinstall the microprocessor in socket 1 and restart the server. 5. (Trained service technician only) Replace the failing microprocessor. 6. (Trained service technician only) Replace the system board.
Sensor Pwr Rail E Fault has transitioned to non-recoverable.	Error	A sensor has changed to Nonrecoverable state.	<ol style="list-style-type: none"> 1. Turn off the server and disconnect it from power. 2. (Trained service technician only) Remove the PCI riser card from PCI riser-card connector 2 and the microprocessor from socket 2. 3. Restart the server. 4. Reinstall each device, one at a time, starting the server each time to isolate the failing device. 5. Replace the failing device. 6. (Trained service technician only) Replace the system board.
Sensor PS <i>n</i> Therm Fault has transitioned to critical from a less severe state. (<i>n</i> = power supply number)	Error	A sensor has changed to Critical state from a less severe state.	<ol style="list-style-type: none"> 1. Make sure that there are no obstructions, such as bundled cables, to the airflow from the power-supply fan. 2. Replace power supply <i>n</i>. (<i>n</i> = power supply number)

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Sensor PS n 12V OV Fault has transitioned to non-recoverable. (n = power supply number)	Error	A sensor has changed to Nonrecoverable state.	<ol style="list-style-type: none"> 1. Check the OVER SPEC LED and power-channel (A, B, C, D, E, and AUX) error LEDs on the system board. See the information about the OVER SPEC LED in “Power-supply LEDs” on page 60. 2. Remove the power supplies. 3. Replace power supply n. 4. (Trained service technician only) Replace the system board. <p>(n = power supply number)</p>
Sensor PS n 12V UV Fault has transitioned to non-recoverable.	Error	A sensor has changed to Nonrecoverable state.	<ol style="list-style-type: none"> 1. Check the OVER SPEC LED and power-channel (A, B, C, D, E, and AUX) error LEDs on the system board. See the information about the OVER SPEC LED in “Power-supply LEDs” on page 60. 2. Remove the power supplies. 3. Replace power supply n. 4. (Trained service technician only) Replace the system board. <p>(n = power supply number)</p>
Sensor PS n 12V OC Fault has transitioned to non-recoverable. (n = power supply number)	Error	A sensor has changed to Nonrecoverable state.	<ol style="list-style-type: none"> 1. Check the OVER SPEC LED and power-channel (A, B, C, D, E, and AUX) error LEDs on the system board. See the information about the OVER SPEC LED in “Light path diagnostics LEDs” on page 57. 2. Remove the power supplies. 3. Replace power supply n. 4. (Trained service technician only) Replace the system board. <p>(n = power supply number)</p>

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Sensor PS n VCO Fault has transitioned to non-recoverable. (n = power supply number)	Error	A sensor has changed to Nonrecoverable state.	<ol style="list-style-type: none"> 1. Check the power supply n LEDs. 2. Replace the failing power supply. (n = power supply number)
Redundancy Power Unit has been reduced.	Error	Redundancy has been lost and is insufficient to continue operation.	<ol style="list-style-type: none"> 1. Check the LEDs for both power supplies. 2. Follow the actions in “Power-supply LEDs” on page 60.
Redundancy Cooling Zone 1 has been reduced.	Error	Redundancy has been lost and is insufficient to continue operation.	<ol style="list-style-type: none"> 1. Make sure that the connector on fan 1 is not damaged. 2. Make sure that the fan 1 connector on the system board is not damaged. 3. Make sure that the fan is correctly installed. 4. Reseat the fan. 5. Replace the fan.
Redundancy Cooling Zone 2 has been reduced.	Error	Redundancy has been lost and is insufficient to continue operation.	<ol style="list-style-type: none"> 1. Make sure that the connector on fan 2 is not damaged. 2. Make sure that the fan 2 connector on the system board is not damaged. 3. Make sure that the fan is correctly installed. 4. Reseat the fan. 5. Replace the fan.
Redundancy Cooling Zone 3 has been reduced.	Error	Redundancy has been lost and is insufficient to continue operation.	<ol style="list-style-type: none"> 1. Make sure that the connector on fan 3 is not damaged. 2. Make sure that the fan 3 connector on the system board is not damaged. 3. Make sure that the fan is correctly installed. 4. Reseat the fan. 5. Replace the fan.
Sensor RAID Error has transitioned to critical from a less severe state.	Error	A sensor has changed to Critical state from a less severe state.	<ol style="list-style-type: none"> 1. Check the hard disk drive LEDs. 2. Reseat the hard disk drive for which the status LED is lit. 3. Replace the defective hard disk drive.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
The Drive <i>n</i> Status has been removed from unit Drive 0 Status. (<i>n</i> = hard disk drive number)	Error	A drive has been removed.	Reseat hard disk drive <i>n</i> . (<i>n</i> = hard disk drive number)
The Drive <i>n</i> Status has been disabled due to a detected fault. (<i>n</i> = hard disk drive number)	Error	A drive has been disabled because of a fault.	<ol style="list-style-type: none"> 1. Run the hard disk drive diagnostic test on drive <i>n</i>. 2. Reseat the following components: <ol style="list-style-type: none"> a. Hard disk drive b. Cable from the system board to the backplane 3. Replace the following components one at a time, in the order shown, restarting the server each time: <ol style="list-style-type: none"> a. Hard disk drive b. Cable from the system board to the backplane c. Hard disk drive backplane (<i>n</i> = hard disk drive number)
Array %1 is in critical condition. (%1 = CIM_ComputerSystem.ElementName)	Error	An array is in Critical state. (Sensor = Drive <i>n</i> Status) (<i>n</i> = hard disk drive number)	Replace the hard disk drive that is indicated by a lit status LED.
Array %1 has failed. (%1 = CIM_ComputerSystem.ElementName)	Error	An array is in Failed state. (Sensor = Drive <i>n</i> Status) (<i>n</i> = hard disk drive number)	Replace the hard disk drive that is indicated by a lit status LED.
Memory uncorrectable error detected for DIMM All DIMMs on Memory Subsystem All DIMMs.	Error	A memory uncorrectable error has occurred.	<ol style="list-style-type: none"> 1. If the server failed the POST memory test, reseat the DIMMs. 2. Replace any DIMM that is indicated by a lit error LED. Note: You do not have to replace DIMMs by pairs. 3. Run the Setup utility to enable all the DIMMs. 4. Run the DSA memory test.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Memory Logging Limit Reached for DIMM All DIMMs on Memory Subsystem All DIMMs.	Error	The memory logging limit has been reached.	<ol style="list-style-type: none"> 1. Update the UEFI to the latest level. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 2. Reseat the DIMMs and run the DSA memory test. 3. Replace any DIMM that is indicated by a lit error LED.
Memory DIMM Configuration Error for All DIMMs on Memory Subsystem All DIMMs.	Error	A DIMM configuration error has occurred.	Make sure that DIMMs are installed in the correct sequence and have the same size, type, speed, and technology.
Memory uncorrectable error detected for DIMM One of the DIMMs on Memory Subsystem One of the DIMMs.	Error	A memory uncorrectable error has occurred.	<ol style="list-style-type: none"> 1. If the server failed the POST memory test, reseat the DIMMs. 2. Replace any DIMM that is indicated by a lit error LED. Note: You do not have to replace DIMMs by pairs. 3. Run the Setup utility to enable all the DIMMs. 4. Run the DSA memory test.
Memory Logging Limit Reached for DIMM One of the DIMMs on Memory Subsystem One of the DIMMs.	Error	The memory logging limit has been reached.	<ol style="list-style-type: none"> 1. Update the UEFI to the latest level. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 2. Reseat the DIMMs and run the DSA memory test. 3. Replace any DIMM that is indicated by a lit error LED.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Memory DIMM Configuration Error for One of the DIMMs on Memory Subsystem One of the DIMMs.	Error	A DIMM configuration error has occurred.	Make sure that DIMMs are installed in the correct sequence and have the same size, type, speed, and technology.
Memory uncorrectable error detected for DIMM <i>n</i> Status on Memory Subsystem DIMM <i>n</i> Status. (<i>n</i> = DIMM number)	Error	A memory uncorrectable error has occurred.	<ol style="list-style-type: none"> 1. If the server failed the POST memory test, reseal the DIMMs. 2. Replace any DIMM that is indicated by a lit error LED. Note: You do not have to replace DIMMs by pairs. 3. Run the Setup utility to enable all the DIMMs. 4. Run the DSA memory test. 5. (Trained service technician only) Replace the system board.
Memory Logging Limit Reached for DIMM <i>n</i> Status on Memory Subsystem DIMM <i>n</i> Status. (<i>n</i> = DIMM number)	Error	The memory logging limit has been reached.	<ol style="list-style-type: none"> 1. Update the UEFI to the latest level. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 2. Reseat the DIMMs and run the DSA memory test. 3. Replace any DIMM that is indicated by a lit error LED.
Memory DIMM Configuration Error for DIMM <i>n</i> Status on Memory Subsystem DIMM <i>n</i> Status. (<i>n</i> = DIMM number)	Error	A DIMM configuration error has occurred.	Make sure that DIMMs are installed in the correct sequence and have the same size, type, speed, and technology.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
<p>Sensor DIMM <i>n</i> Temp has transitioned to critical from a less severe state. (<i>n</i> = DIMM number)</p>	Error	<p>A sensor has changed to Critical state from a less severe state.</p>	<ol style="list-style-type: none"> 1. Make sure that the fans are operating, that there are no obstructions to the airflow, that the air baffles are in place and correctly installed, and that the server cover is installed and completely closed. 2. If a fan has failed, complete the action for a fan failure. 3. Replace DIMM <i>n</i>. <p>(<i>n</i> = DIMM number)</p>
<p>A PCI PERR has occurred on system %1. (%1 = CIM_ComputerSystem.ElementName)</p>	Error	<p>A PCI PERR has occurred. (Sensor = PCI Slot <i>n</i>; <i>n</i> = PCI slot number)</p>	<ol style="list-style-type: none"> 1. Check the riser-card LEDs. 2. Reseat the affected adapters and riser card. 3. Update the server and adapter firmware (UEFI and IMM). Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 4. Remove the adapter from slot <i>n</i>. 5. Replace the PCIe adapter. 6. Replace riser card <i>n</i>. <p>(<i>n</i> = PCI slot number)</p>

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
<p>A PCI SERR has occurred on system %1. (%1 = CIM_ComputerSystem.ElementName)</p>	<p>Error</p>	<p>A PCI SERR has occurred. (Sensor = PCI Slot <i>n</i>; <i>n</i> = PCI slot number)</p>	<ol style="list-style-type: none"> 1. Check the riser-card LEDs. 2. Reseat the affected adapters and riser card. 3. Update the server and adapter firmware (UEFI and IMM). Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 4. Remove the adapter from slot <i>n</i>. 5. Replace the PCIe adapter. 6. Replace riser card <i>n</i>. (<i>n</i> = PCI slot number)
<p>A PCI PERR has occurred on system %1. (%1 = CIM_ComputerSystem.ElementName)</p>	<p>Error</p>	<p>A PCI PERR has occurred. (Sensor = One of PCI Err)</p>	<ol style="list-style-type: none"> 1. Check the riser-card LEDs. 2. Reseat the affected adapters and riser card. 3. Update the server and adapter firmware (UEFI and IMM). Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 4. Remove both adapters. 5. Replace the PCIe adapter. 6. Replace the riser card. 7. (Trained service technician only) Replace the system board.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
<p>A PCI SERR has occurred on system %1. (%1 = CIM_ComputerSystem.ElementName)</p>	<p>Error</p>	<p>A PCI SERR has occurred. (Sensor = One of PCI Err)</p>	<ol style="list-style-type: none"> 1. Check the riser-card LEDs. 2. Reseat the affected adapters and riser card. 3. Update the server and adapter firmware (UEFI and IMM). Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 4. Remove both adapters. 5. Replace the PCIe adapter. 6. Replace the riser card. 7. (Trained service technician only) Replace the system board.
<p>Fault in slot System board on system %1. (%1 = CIM_ComputerSystem.ElementName)</p>	<p>Error</p>		<ol style="list-style-type: none"> 1. Check the riser-card LEDs. 2. Reseat the affected adapters and riser card. 3. Update the server and adapter firmware (UEFI and IMM). Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code. 4. Remove both adapters. 5. Replace the PCIe adapter. 6. Replace the riser card. 7. (Trained service technician only) Replace the system board.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Redundancy Bckup Mem Status has been reduced.	Error	Redundancy has been lost and is insufficient to continue operation.	<ol style="list-style-type: none"> 1. Check the system-event log for DIMM failure events (uncorrectable or PFA) and correct the failures. 2. Re-enable mirroring in the Setup utility.
Sensor Planar Fault has transitioned to critical from a less severe state.	Error	A sensor has changed to Critical state from a less severe state.	(Trained service technician only) Replace the system board.
IMM Network Initialization Complete.	Info	An IMM network has completed initialization.	No action; information only.
Certificate Authority %1 has detected a %2 Certificate Error. (%1 = IBM_CertificateAuthority.CADistinguishedName; %2 = CIM_PublicKeyCertificate.ElementName)	Error	A problem has occurred with the SSL Server, SSL Client, or SSL Trusted CA certificate that has been imported into the IMM. The imported certificate must contain a public key that corresponds to the key pair that was previously generated by the Generate a New Key and Certificate Signing Request link.	<ol style="list-style-type: none"> 1. Make sure that the certificate that you are importing is correct. 2. Try importing the certificate again.
Ethernet Data Rate modified from %1 to %2 by user %3. (%1 = CIM_EthernetPort.Speed; %2 = CIM_EthernetPort.Speed; %3 = user ID)	Info	A user has modified the Ethernet port data rate.	No action; information only.
Ethernet Duplex setting modified from %1 to %2 by user %3. (%1 = CIM_EthernetPort.FullDuplex; %2 = CIM_EthernetPort.FullDuplex; %3 = user ID)	Info	A user has modified the Ethernet port duplex setting.	No action; information only.
Ethernet MTU setting modified from %1 to %2 by user %3. (%1 = CIM_EthernetPort.ActiveMaximumTransmissionUnit; %2 = CIM_EthernetPort.ActiveMaximumTransmissionUnit; %3 = user ID)	Info	A user has modified the Ethernet port MTU setting.	No action; information only.
Ethernet Duplex setting modified from %1 to %2 by user %3. (%1 = CIM_EthernetPort.NetworkAddresses; %2 = CIM_EthernetPort.NetworkAddresses; %3 = user ID)	Info	A user has modified the Ethernet port MAC address setting.	No action; information only.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Ethernet interface %1 by user %2. (%1 = CIM_EthernetPort. EnabledState; %2 = user ID)	Info	A user has enabled or disabled the Ethernet interface.	No action; information only.
Hostname set to %1 by user %2. (%1 = CIM_DNSProtocol Endpoint.Hostname; %2 = user ID)	Info	A user has modified the host name of the IMM.	No action; information only.
IP address of network interface modified from %1 to %2 by user %3. (%1 = CIM_IPProtocolEndpoint. IPv4Address; %2 = CIM_StaticIPAssignment SettingData.IPAddress; %3 = user ID)	Info	A user has modified the IP address of the IMM.	No action; information only.
IP subnet mask of network interface modified from %1 to %2 by user %3s. (%1 = CIM_IPProtocolEndpoint .SubnetMask; %2 = CIM_StaticIPAssignment SettingData.SubnetMask; %3 = user ID)	Info	A user has modified the IP subnet mask of the IMM.	No action; information only.
IP address of default gateway modified from %1 to %2 by user %3s. (%1 = CIM_IPProtocolEndpoint. GatewayIPv4Address; %2 = CIM_StaticIPAssignment SettingData.Default GatewayAddress; %3 = user ID)	Info	A user has modified the default gateway IP address of the IMM.	No action; information only.
OS Watchdog response %1 by %2. (%1 = Enabled or Disabled; %2 = user ID)	Info	A user has enabled or disabled an OS Watchdog.	No action; information only.
DHCP[%1] failure, no IP address assigned. (%1 = IP address, xxx.xxx.xxx.xxx)	Info	A DHCP server has failed to assign an IP address to the IMM.	<ol style="list-style-type: none"> 1. Make sure that the network cable is connected. 2. Make sure that there is a DHCP server on the network that can assign an IP address to the IMM.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Remote Login Successful. Login ID: %1 from %2 at IP address %3. (%1 = user ID; %2 = ValueMap(CIM_ProtocolEndpoint.ProtocolIFType; %3 = IP address, xxx.xxx.xxx.xxx)	Info	A user has successfully logged in to the IMM.	No action; information only.
Attempting to %1 server %2 by user %3. (%1 = Power Up, Power Down, Power Cycle, or Reset; %2 = IBM_ComputerSystem.ElementName; %3 = user ID)	Info	A user has used the IMM to perform a power function on the server.	No action; information only.
Security: Userid: '%1' had %2 login failures from WEB client at IP address %3. (%1 = user ID; %2 = MaximumSuccessiveLoginFailures (currently set to 5 in the firmware); %3 = IP address, xxx.xxx.xxx.xxx)	Error	A user has exceeded the maximum number of unsuccessful login attempts from a Web browser and has been prevented from logging in for the lockout period.	<ol style="list-style-type: none"> 1. Make sure that the correct login ID and password are being used. 2. Have the system administrator reset the login ID or password.
Security: Login ID: '%1' had %2 login failures from CLI at %3. (%1 = user ID; %2 = MaximumSuccessiveLoginFailures (currently set to 5 in the firmware); %3 = IP address, xxx.xxx.xxx.xxx)	Error	A user has exceeded the maximum number of unsuccessful login attempts from the command-line interface and has been prevented from logging in for the lockout period.	<ol style="list-style-type: none"> 1. Make sure that the correct login ID and password are being used. 2. Have the system administrator reset the login ID or password.
Remote access attempt failed. Invalid userid or password received. Userid is '%1' from WEB browser at IP address %2. (%1 = user ID; %2 = IP address, xxx.xxx.xxx.xxx)	Error	A user has attempted to log in from a Web browser by using an invalid login ID or password.	<ol style="list-style-type: none"> 1. Make sure that the correct login ID and password are being used. 2. Have the system administrator reset the login ID or password.
Remote access attempt failed. Invalid userid or password received. Userid is '%1' from TELNET client at IP address %2. (%1 = user ID; %2 = IP address, xxx.xxx.xxx.xxx)	Error	A user has attempted to log in from a Telnet session by using an invalid login ID or password.	<ol style="list-style-type: none"> 1. Make sure that the correct login ID and password are being used. 2. Have the system administrator reset the login ID or password.
The Chassis Event Log (CEL) on system %1 cleared by user %2. (%1 = CIM_ComputerSystem.ElementName; %2 = user ID)	Info	A user has cleared the IMM event log.	No action; information only.
IMM reset was initiated by user %1. (%1 = user ID)	Info	A user has initiated a reset of the IMM.	No action; information only.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
ENET[0] DHCP-HSTN=%1, DN=%2, IP@=%3, SN=%4, GW@=%5, DNS1@=%6. (%1 = CIM_DNSProtocol Endpoint.Hostname; %2 = CIM_DNSProtocol Endpoint.DomainName; %3 = CIM_IPProtocol Endpoint.IPv4Address; %4 = CIM_IPProtocolEndpoint.SubnetMask; %5 = IP address, xxx.xxx.xxx.xxx; %6 = IP address, xxx.xxx.xxx.xxx)	Info	The DHCP server has assigned an IMM IP address and configuration.	No action; information only.
ENET[0] IP-Cfg:HstName=%1, IP@=%2, NetMsk=%3, GW@=%4. (%1 = CIM_DNSProtocol Endpoint.Hostname; %2 = CIM_StaticIPSettingData.IPv4Address; %3 = CIM_StaticIPSettingData.SubnetMask; %4 = CIM_StaticIPSettingData.DefaultGatewayAddress)	Info	An IMM IP address and configuration have been assigned using client data.	No action; information only.
LAN: Ethernet[0] interface is no longer active.	Info	The IMM Ethernet interface has been disabled.	No action; information only.
LAN: Ethernet[0] interface is now active.	Info	The IMM Ethernet interface has been enabled.	No action; information only.
DHCP setting changed to by user %1. (%1 = user ID)	Info	A user has changed the DHCP mode.	No action; information only.
IMM: Configuration %1 restored from a configuration file by user %2. (%1 = CIM_ConfigurationData.ConfigurationName; %2 = user ID)	Info	A user has restored the IMM configuration by importing a configuration file.	No action; information only.
Watchdog %1 Screen Capture Occurred. (%1 = OS Watchdog or Loader Watchdog)	Error	An operating-system error has occurred, and the screen capture was successful.	<ol style="list-style-type: none"> 1. Reconfigure the watchdog timer to a higher value. 2. Make sure that the IMM Ethernet over USB interface is enabled. 3. Reinstall the RNDIS or cdc_ether device driver for the operating system. 4. Disable the watchdog. 5. Check the integrity of the installed operating system.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
Watchdog %1 Failed to Capture Screen. (%1 = OS Watchdog or Loader Watchdog)	Error	An operating-system error has occurred, and the screen capture failed.	<ol style="list-style-type: none"> 1. Reconfigure the watchdog timer to a higher value. 2. Make sure that the IMM Ethernet over USB interface is enabled. 3. Reinstall the RNDIS or cdc_ether device driver for the operating system. 4. Disable the watchdog. 5. Check the integrity of the installed operating system. 6. Update the IMM firmware. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
Running the backup IMM main application.	Error	The IMM has resorted to running the backup main application.	Update the IMM firmware. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
Please ensure that the IMM is flashed with the correct firmware. The IMM is unable to match its firmware to the server.	Error	The server does not support the installed IMM firmware version.	Update the IMM firmware to a version that the server supports. Important: Some cluster solutions require specific code levels or coordinated code updates. If the device is part of a cluster solution, verify that the latest level of code is supported for the cluster solution before you update the code.
IMM reset was caused by restoring default values.	Info	The IMM has been reset because a user has restored the configuration to its default settings.	No action; information only.
IMM clock has been set from NTP server %1. (%1 = IBM_NTPService.ElementName)	Info	The IMM clock has been set to the date and time that is provided by the Network Time Protocol server.	No action; information only.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
SSL data in the IMM configuration data is invalid. Clearing configuration data region and disabling SSL+H25.	Error	There is a problem with the certificate that has been imported into the IMM. The imported certificate must contain a public key that corresponds to the key pair that was previously generated through the Generate a New Key and Certificate Signing Request link.	<ol style="list-style-type: none"> 1. Make sure that the certificate that you are importing is correct. 2. Try to import the certificate again.
Flash of %1 from %2 succeeded for user %3. (%1 = CIM_ManagedElement.ElementName; %2 = Web or LegacyCLI; %3 = user ID)	Info	A user has successfully updated one of the following firmware components: <ul style="list-style-type: none"> • IMM main application • IMM boot ROM • UEFI firmware • Diagnostics • System power backplane • Remote expansion enclosure power backplane • Integrated service processor • Remote expansion enclosure processor 	No action; information only.
Flash of %1 from %2 failed for user %3. (%1 = CIM_ManagedElement.ElementName; %2 = Web or LegacyCLI; %3 = user ID)	Info	An attempt to update a firmware component from the interface and IP address has failed.	Try to update the firmware again.
The Chassis Event Log (CEL) on system %1 is 75% full. (%1 = CIM_ComputerSystem.ElementName)	Info	The IMM event log is 75% full. When the log is full, older log entries are replaced by newer ones.	To avoid losing older log entries, save the log as a text file and clear the log.
The Chassis Event Log (CEL) on system %1 is 100% full. (%1 = CIM_ComputerSystem.ElementName)	Info	The IMM event log is full. When the log is full, older log entries are replaced by newer ones.	To avoid losing older log entries, save the log as a text file and clear the log.
%1 Platform Watchdog Timer expired for %2. (%1 = OS Watchdog or Loader Watchdog; %2 = OS Watchdog or Loader Watchdog)	Error	A Platform Watchdog Timer Expired event has occurred.	<ol style="list-style-type: none"> 1. Reconfigure the watchdog timer to a higher value. 2. Make sure that the IMM Ethernet over USB interface is enabled. 3. Reinstall the RNDIS or cdc_ether device driver for the operating system. 4. Disable the watchdog. 5. Check the integrity of the installed operating system.

Table 9. Integrated management module error messages (continued)

<ul style="list-style-type: none"> • Follow the suggested actions in the order in which they are listed in the Action column until the problem is solved. • See Chapter 4, “Parts listing, Type 7947 server,” on page 135 to determine which components are customer replaceable units (CRU) and which components are field replaceable units (FRU). • If an action step is preceded by “(Trained service technician only),” that step must be performed only by a trained service technician. 			
IMM Test Alert Generated by %1. (%1 = user ID)	Info	A user has generated a test alert from the IMM.	No action; information only.
Security: Userid: '%1' had %2 login failures from an SSH client at IP address %3. (%1 = user ID; %2 = MaximumSuccessive LoginFailures (currently set to 5 in the firmware); %3 = IP address, xxx.xxx.xxx.xxx)	Error	A user has exceeded the maximum number of unsuccessful login attempts from SSH and has been prevented from logging in for the lockout period.	<ol style="list-style-type: none"> 1. Make sure that the correct login ID and password are being used. 2. Have the system administrator reset the login ID or password.